


# Cross Section of the Upright Piano



- |     |                                |     |  |
|-----|--------------------------------|-----|--|
| 1.  | <u>String</u>                  | 30. | <u>Letoff Button</u>                   |
| 2.  | <u>Damper felt</u>             | 31. | <u>Bridle Strap</u>                    |
| 3.  | <u>Damper head</u>             | 32. | <u>Letoff Button Punching</u>          |
| 4.  | <u>Damper block</u>            | 33. | <u>Backcheck Wire</u>                  |
| 5.  | <u>Hammer</u>                  | 34. | <u>Damper Spoon</u>                    |
| 6.  | <u>Damper Wire</u>             | 35. | <u>Jack Flange</u>                     |
| 7.  | <u>Spring Rail Felt</u>        | 36. | <u>Bridle Wire</u>                     |
| 8.  | <u>Spring Rail</u>             | 37. | <u>Jack Spring</u>                     |
| 9.  | <u>Hammer Shank</u>            | 38. | <u>Wippen Flange</u>                   |
| 10. | <u>Hammer Rail Cloth</u>       | 39. | <u>Wippen</u>                          |
| 11. | <u>Hammer Rail</u>             | 40. | <u>Sustaining Pedal Connecting Rod</u> |
| 12. | <u>Damper Lever</u>            | 41. | <u>Lower Action Rail/Sticker Rail</u>  |
| 13. | <u>Damper Spring</u>           | 42. | <u>Sticker</u>                         |
| 14. | <u>Hammer Butt Spring</u>      | 43. | <u>Sticker Flange</u>                  |
| 15. | <u>Damper Flange</u>           | 44. | <u>Sticker Tongue</u>                  |
| 16. | <u>Hammer Butt Felt</u>        | 45. | <u>Sticker Cloth</u>                   |
| 17. | <u>Hammer Butt Buckskin</u>    | 46. | <u>Capstan Screw</u>                   |
| 18. | <u>Hammer Butt</u>             | 47. | <u>Back Rail Cloth</u>                 |
| 19. | <u>Catcher Shank</u>           | 48. | <u>Key</u>                             |
| 20. | <u>Catcher</u>                 | 49. | <u>Key Lead</u>                        |
| 21. | <u>Catcher Buckskin</u>        | 50. | <u>Balance Rail</u>                    |
| 22. | <u>Backcheck Felt</u>          | 51. | <u>Key Button</u>                      |
| 23. | <u>Backcheck</u>               | 52. | <u>Balance Rail Key Pin</u>            |
| 24. | <u>Damper Lift Rod</u>         | 53. | <u>Balance Rail Punching</u>           |
| 25. | <u>Hammer Butt Flange</u>      | 54. | <u>Key Frame</u>                       |
| 26. | <u>Main Action Rail</u>        | 55. | <u>Front Rail</u>                      |
| 27. | <u>Jack</u>                    | 56. | <u>Front Rail Punching</u>             |
| 28. | <u>Letoff Regulating Screw</u> | 57. | <u>Front Rail Key Pin</u>              |
| 29. | <u>Letoff Rail</u>             |     |  |